


Magazine loader for Beneli MP90 .32




Step 1: Slide the magazine into the loader




Step 2: Press the top of the loader down




Step 3: Insert base of cartridge into top of magazine



Step 4: Release top of loader



Step 5: Push cartridge into magazine



Step 6: Repeat steps 1-5

USE SILICONE GREASE WHEN NEEDED